


MICROSmart

This sheet provides brief operating instructions of the MicroSmart I/O modules. For details, see the MicroSmart User's Manual.

- FC4A-N16B3, FC4A-N32B3, FC4A-T16K3
 FC4A-T16S3, FC4A-T32K3, FC4A-T32S3
 FC4A-M24BR2, FC4A-L03A1, FC4A-L03AP1
 FC4A-J2A1, FC4A-K1A1


Wiring Example

Use an IEC 60127-approved fuse on the output circuit to meet voltage and current requirements. For details of output module specifications, see the MicroSmart User's Manual.




Terminal numbers are indicated on the module.


FC4A-N16B3 Source Input Wiring




FC4A-N16B3 Sink Input Wiring




FC4A-N32B3 Source Input Wiring




FC4A-N32B3 Sink Input Wiring




FC4A-M24BR2 Source Input Wiring




FC4A-M24BR2 Sink Input Wiring




FC4A-T16K3




FC4A-T16S3




FC4A-T32K3




FC4A-T32K3




FC4A-T32S3




FC4A-T32S3




FC4A-M24BR2 Relay Output Wiring




FC4A-L03A1




FC4A-L03AP1



FC4A-J2A1




FC4A-K1A1




Dimensions


FC4A-N16B3, FC4A-T16K3, FC4A-T16S3




FC4A-N32B3, FC4A-T32K3, FC4A-T32S3



FC4A-M24BR2




FC4A-L03A1, FC4A-L03AP1, FC4A-J2A1, FC4A-K1A1



* 8.5 mm when the clamp is pulled out.
 Dimensions in mm.

Applicable Ferrule Dimensions (mm)

To crimp the ferrules shown below, use a special crimping tool (CRIMPFOX ZA 3).



() indicates the Type No. of Phoenix Contact.

Recommended Screwdriver

When wiring the Phoenix Contact terminal block, use the recommended screwdriver.
 (Phoenix Contact Type No.: SZS 0.4x2.5)

Safety Precautions

- Special expertise is required to use the MicroSmart.
- Read this instruction sheet and the user's manual to make sure of correct operation before starting installation, wiring, operation, maintenance, and inspection of the MicroSmart.
 - Keep this instruction sheet at the end user.
 - All MicroSmart modules are manufactured under IEC's rigorous quality control system, but users must add a backup or failsafe provision to the control system using the MicroSmart in applications where heavy damage or personal injury may be caused in case the MicroSmart should fail.
 - Install the MicroSmart according to instructions described in this instruction sheet and the user's manual. Improper installation will result in falling, failure, or malfunction of the MicroSmart.
 - Make sure that the operating conditions are as described in the user's manual. If you are uncertain about the specifications, contact IEC in advance.
 - In this instruction sheet, safety precautions are categorized in order of importance to Warning and Caution:

Warning

- (Warning notices are used to emphasize that improper operation may cause severe personal injury or death.)
- Turn off the power to the MicroSmart before starting installation, removal, wiring, maintenance, and inspection on the MicroSmart. Failure to turn power off may cause electrical shocks or fire hazard.
- Emergency stop and interlocking circuits must be configured outside the MicroSmart. If such a circuit is configured inside the MicroSmart, failure of the MicroSmart may cause disorder of the control system, damage, or accidents.
- This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only.
- Warning - Explosion Hazard - Substitution of components may impair suitability for Class I, Division 2.
- Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.

Caution

- (Caution notices are used where inattention might cause personal injury or damage to equipment.)
- The MicroSmart is designed for installation in equipment. Do not install the MicroSmart outside equipment.
- Install the MicroSmart in environments described in the user's manual. If the MicroSmart is used in places where the MicroSmart is subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, and excessive shocks, then electrical shocks, fire hazard, or malfunction will result.
- The environment for using the MicroSmart is "Pollution degree 2." The pollution degree refers to a degree of pollution in the micro-environment which determines the effect of pollution on the insulation. Pollution degree 2 defines "Only non-conductive pollution occurs except that occasionally a temporary conductivity caused by condensation is to be expected." Do not use the MicroSmart in environments inferior to the state specified in IEC80664-1.
- Prevent metal fragments and pieces of wire from dropping inside the MicroSmart housing. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.
- Use wires of a proper size to meet voltage and current requirements. Tighten terminal screws to a proper tightening torque of 0.22 to 0.25N·m.
- Use an IEC60127-approved fuse on the power line and output circuit to meet voltage and current requirements. (Recommended fuse: Littelfuse 5x20mm slow-blow type 218000 series/Type T) This is required when exporting equipment containing MicroSmart to Europe.
- Use an EU-approved circuit breaker. This is required when exporting equipment containing MicroSmart to Europe.
- If relays or transistors in the MicroSmart output modules should fail, outputs may remain on or off. For output signals which may cause heavy accidents, provide a monitor circuit outside of the MicroSmart.
- Do not disassemble, repair, or modify the MicroSmart modules.