UL Product iQ™



NKCR.E68961 - AUXILIARY DEVICES

Auxiliary Devices

See General Information for Auxiliary Devices

IDEC CORP

6-64 NISHIMIYAHARA 2-CHOME YODOGAWA-KU, OSAKA 532-0004 JAPAN



Investigated to ANSI/UL 508

AS-interface fail-safe monitors Model(s) SX5A-MBR01, SX5A-MBR02, SX5A-MBR03, SX5A-MBR04

AS-interfaces Model(s) FL1B-CAS2

Auxilary Device Open type Contact Blocks Model(s) HW-U followed by 01 or 10, may be followed by R, may be followed by MAU, may be followed by additional suffixes.

Auxilary Device Open type Direct Adapter for illuminated models Model(s) HW-GA1N

Auxilary Device Open type Dummy contact block Model(s) HW-DB

Auxiliary Devices Model(s) HR5S-C2, followed by B, D-T025, D-T050, D-T100, D-T200, D-T400 or S.

HS1T Auxiliary Devices, Complete Assembly, Cat No. HS1T- followed by A, B, C, D, F, G, H, J, DD, VA, VB, VC, VD, VF, VG, VH, VJ, VW, VX, TA, TB, TC, TD, TF, TG, TH, TJ, XA, XB, XC, XD, XF, XG, XH or XJ, followed by 4 or 7Y, maybe followed by 0, 4 or 8, maybe followed by Z, maybe followed by L, followed by M, G, P, SM, SG, SP, maybe followed by any letter, maybe followed by 1, 2 or 3, maybe followed by additional suffixes. Auxiliary Devices, Switches without Cover, Cat No. HS1T- followed by A, B, C, D, F, G, H, J, DD, VA, VB, VC, VD, VF, VG, VH, VJ, VW, VX, TA, TB, TC, TD, TF, TG, TH, TJ, XA, XB, XC, XD, XF, XG, XH or XJ, followed by 4 or 7Y, maybe followed by 0, 4 or 8, maybe followed by Z, maybe followed by L, maybe followed by any letter, maybe followed by 1, 2 or 3, maybe followed by additional suffixes.

HW-PAQ2, HW-PAQ3, HW-PAQ4

Auxiliary devices, Complete Assembly Model(s) Complete Assembly HS5L- followed by A, B, C, D, F, G, H, J, DD, VA, VB, VC, VD, VF, VG, VH, VJ, VW, VX, TA, TB, TC, TD, TF, TG, TH, TJ, XA, XB, XC, XD, XF, XG, XH or XJ, followed by 4 or 7Y, maybe followed by 0 or 4, maybe followed by L, maybe followed by 01 to 99, followed by M, SM, SG, SP, SR or SL, maybe followed by any letter, maybe followed by 1, 2 or 3, maybe followed by additional suffixes.

Switches without Cover, HSSL- followed by A, B, C, D, F, G, H, J, DD, VA, VB, VC, VD, VF, VG, VH, VJ, VW, VX, TA, TB, TC, TD, TF, TG, TH, TJ, XA, XB, XC, XD, XF, XG, XH or XJ, followed by 4 or 7Y, maybe followed by 0 or 4, maybe followed by L, maybe followed by 01 to 99, maybe followed by any letter, maybe followed by 1, 2 or 3, maybe followed by additional suffixes.

Auxillary Device: Open type Pilot Lights Model(s) AP22M followed by 2 or 2T, followed by Q, followed by 3, 4, H, H2, M, M3 or M4, may be followed by any letters and/or numbers

Cam switches Model(s) ACSNK+, ACSNO+, UCSQM+, UCSQO+

Contact Blocks, "YW/FW/CW Series" Model(s) CW-E01 followed by 1 or 4, followed by B, maybe followed by M, A or V, followed by 1, 2, 4 or F2, followed by E, may be followed 1, 2, 3, 4, 5 or 6, may be followed 1, 2, 3, 4, 5 or 6, followed by 1 or 2 letters.

CW-E10 followed by 1 or 4, followed by B, maybe followed by M, A or V, followed by 1, 2, 4 or F2, followed by E, may be followed 1, 2, 3, 4, 5 or 6, may be followed 1, 2, 3, 4, 5 or 6, followed by 1 or 2 letters.

YW, EW20 followed by 1 or 4, followed by B, maybe followed by M, A or V, followed by 1, 2, 4 or F2, followed by E, may be followed 1, 2, 3, 4, 5 or 6, may be followed 1, 2, 3, 4, 5 or 6, followed by 1 or 2 letters.