



NKCR8.E68961

Auxiliary Devices Certified for Canada - Component

Page Bottom



Auxiliary Devices Certified for Canada - Component

See General Information for Auxiliary Devices Certified for Canada - Component

IDEC CORP

6-64 NISHIMIYAHARA 2-CHOME
YODOGAWA-KU, OSAKA 532-0004 JAPAN

E68961

Combination display lights (Pilot lights), Models SLC30N, SLC40N may be followed by suffixes, may be followed by -NKCR2.

Model LD6A, may be followed by -0, -1, -2, -3, -4 or -5, followed by D, W, G, P or K, may be followed by Z or C, may be followed by Q or D, may be followed by any letter(s) and/or number(s).

Enabling switches, Cat. No. HE1B-M1.

Model HE2B -M2 or -M6 may be followed by additional numbers or letters.

Models HE3B-M2, HE5B-M2 may be followed by additional numbers or letters.

Type HE2G followed by 2, followed by 0, 1, 1S, 2, 2S, 11S, 21S, 12S or 22S, followed by H or C, may be followed by additional letters and/or numbers, followed by blank, B, N, 1Y, 1B or 1N, may be followed by additional letters and/or numbers.

Model HE2G-X followed by 2, followed by 0, 1, 1S, 2, 2S, 11S, 21S, 12S or 22S, followed by H or C, may be followed by additional letters and/or numbers, followed by blank, B, N, 1Y, 1B or 1N, may be followed by additional letters and/or numbers.

Push buttons, Model XW Series.

Models XN Series, XNxx-xxxxxxxx-BC* Series.

Push button switches, Model HA may be followed by 1, may be followed by E, followed by -, may be followed by V, may be followed by 2, followed by S, may be followed by 1 or 2, may be followed by V, may be followed by R, N, Y, B, G, W or S, may be followed by additional letters and/or numbers.

Types XW1E, XA1E, followed by -BV, -LV, or -TV, followed by 3, 4, 5, 3T and 4T, followed by 0 through 3, followed by 1 through 4, may be followed by Q4, Q3, Q2, Q1, may be followed by V, followed by R or R-EMO, RH or RH-EMO, RM, N, Y, B, G, W or S.

Model XA1E Unibody Type.

Grip switch enclosure, Model HE9Z.

Auxiliary device, Model HS5E Series.

LED illuminated display lights, Model SLC followed by 30 or 40, followed by -0101, -0102, -0103 or -0202, may be followed by additional suffixes; Model SLD followed by 24, may be followed by additional suffixes.

Open auxiliary devices - AS-interface stop at work slave, Models XW1E, XA1E, may be preceded by prefix FB1W, followed by BV or LV, followed by 3, 4 or 5, followed by Z, followed by 10 or 11, may be followed by 4 through 24, followed by C1 or C2, followed by R, RH or N, may be followed by Y, may be followed by 0 or 1, may be followed by 1 or 2.

Pushbutton switches, AB6E series; Model AB6E, followed by hyphen and 3 or 4, followed by BV, followed by 01 or 02, may be followed by P, may be followed by T, may be followed by any letters and/or numbers.

Pushbutton switches, HE6B series: Cat. Nos. HE6B-M2++##, HE6B-M2++V## and HE6B-M2++##-TK2546-1.

Pushbutton switch, Model XA1E Unibody Type.

++ - replaced by 00, 01, 02, 10, 11 or 20.

- replaced by one letter or number, or blank.