


# Application Notes



## How to open ZNV program in NV4

- 1) First, store a ZNV file in a HGDATA01 → NVDATA folder.




- 2) Launch NV4 software.

- 3) Click on Setup in NV4 and Select “External Memory Device” in Communication Settings.



4) Go to Online → Upload



5) Select the Drive → HGDATA01. Click OK to upload.

